



Installer operation manual - Wired controller

Heat Pump air/water "inverter"

Baxi HP40-XX-MB

Mono 2 AWHP 4-16MR

- This manual gives detailed description of the precautions that should be brought to your attention during operation.
- In order to ensure correct service of the wired controller, please read this manual carefully before using the unit.
- For convenience of future reference, keep this manual after reading it.

CONTENTS

1 GENERAL SAFETY PRECAUTIONS	1
• 1.1 About the documentation	1
• 1.2 For the user	2
2 A GLANCE OF THE USER INTERFACE	3
• 2.1 The appearance of the wired controller.....	3
• 2.2 Status icons.....	4
3 USING HOME PAGES	5
• 3.1 About home pages	5
4 MENU STRUCTURE	7
• 4.1 About the menu structure	7
• 4.2 To go to the menu structure	7
• 4.3 To navigate in the menu structure	7
5 BASIC USAGE	8
• 5.1 Screen Unlock	8
• 5.2 Turning ON/OFF controls.....	9
• 5.3 Adjusting the temperature	13
• 5.4 Adjusting space operation mode	14
6 INSTALLATION MANUAL	16
• 6.1 Safety precaution	16
• 6.2 Other Precautions	18
• 6.3 Installation procedure and matching setting of wired controller.....	19
• 6.4 Front cover installation	23
7 MODBUS MAPPING TABLE	24
• 7.1 Modbus Port Communication Specification	24

1 GENERAL SAFETY PRECAUTIONS

1.1 About the documentation

- The precautions described in this document cover very important topics, follow them carefully.
- All activities described in the installation manual must be performed by an authorized installer.

1.1.1 Meaning of warnings and symbols

DANGER

Indicates a situation that results in death or serious injury.

DANGER: RISK OF ELECTROCUTION

Indicates a situation that could result in electrocution.

DANGER: RISK OF BURNING

Indicates a situation that could result in burning because of extreme hot or cold temperatures.

WARNING

Indicates a situation that could result in death or serious injury.

CAUTION

Indicates a situation that could result in minor or moderate injury.

NOTE

Indicates a situation that could result in equipment or property damage.

INFORMATION

Indicates useful tips or additional information.

1.2 For the user

- If you are not sure how to operate the unit, contact your installer.
- The appliance is not intended for use by persons, including children, with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children must be supervised to ensure that they do not play with the product.

CAUTION

Do NOT rinse the unit. This may cause electric shocks or fire.

NOTE

- Do NOT place any objects or equipment on top of the unit.
- Do NOT sit, climb or stand on the unit.


- Units are marked with the following symbol:




This means that electrical and electronic products may not be mixed with unsorted household waste. Do not try to dismantle the system yourself: the dismantling of the system, treatment of the refrigerant, of oil and of other parts must be done by an authorized installer and must comply with applicable legislation. Units must be treated at a specialized treatment facility for reuse, recycling and recovery. By ensuring this product is disposed of correctly, you will help to prevent potential negative consequences for the environment and human health. For more information, contact your installer or local authority.

2 A GLANCE OF THE USER INTERFACE

2.1 The appearance of the wired controller



2.2 Status icons



3 USING HOME PAGES

3.1 About home pages

You can use the home pages to read out and change settings that are meant for daily usage. What you can see and do on the home pages is described where applicable. Depending on the system layout, the following home pages may be possible:








- Room desired temperature (ROOM)
- Water flow desired temperature (MAIN)
- Domestic Hot Water (DHW) tank actual temperature (TANK)

home page1

If you have set the WATER FLOW TEMP. as YES and ROOM TEMP. as NON, the system functions include floor heating and making hot water. The following page will appear:

NOTE

All the pictures in the manual are shown for explanatory purposes, the actual screens may differ.








01-01-2018  23:59   13°		
 23 °C 	ON 	 38 °C

home page2

If you have set the WATER FLOW TEMP. as NON and ROOM TEMP. as YES, the system functions include floor heating and making hot water. The following page will appear:


NOTE

The wired controller should be installed in the floor heating room to check the room temperature.

01-01-2018  23:59   13°		
 23.5 °C 	ON 	 38 °C


home page3 :

If the DHW MODE is set NON , and if "WATER FLOW TEMP." is set YES, "ROOM TEMP." is set YES, There will be a main page and an additional one. The system functions include floor heating and space cooling for fan coil, home page 3 will appear:



home page4 :

If the DHW MODE is set YES. There will be a main page and an additional one. The system functions include floor heating, space cooling for fan coil and domestic hot water, home page 4 will appear:



4 MENU STRUCTURE

4.1 About the menu structure

You can use the menu structure to read out and configure settings that are NOT meant for daily usage. What you can see and do in the menu structure is described where applicable.

4.2 To go to the menu structure

From a home page, press "MENU". Result: The menu structure appears:

MENU	1/2
OPERATION MODE	
PRESET TEMPERATURE	
DOMESTIC HOT WATER(DHW)	
SCHEDULE	
OPTIONS	
CHILD LOCK	
ENTER	


MENU	2/2
SERVICE INFORMATION	
OPERATION PARAMRTER	
FOR SERVICEMAN	
WLAN SETTING	
ENTER	


4.3 To navigate in the menu structure




Use "▼", "▲" to scroll.


5 BASIC USAGE


5.1 Screen Unlock


If the icon  is on the screen, the controller is locked. The following page is displayed:



Press any key, the icon  will flash. Long press the  key. The icon  will disappear, the interface can be controlled.








The interface will be locked if there is no handling for a long time (about 120 seconds). If the interface is unlocked, long press , the interface will be locked.




5.2 Turning ON/OFF controls


- Use the interface to turn on or off the unit for space heating or cooling. The ON/OFF of the unit can be controlled by the interface if the ROOM THERMOSTAT is NON. (See "ROOM THERMOSTAT SETTING" in «Installation, User and Service Manual»).
- Press "◀", "▲" on home page, the black cursor will appear:




1) When the cursor is on the temperature of space operation mode side (Including heat mode , cool mode  and auto mode ) , press  key to turn on/off space heating or cooling.





If the DHW TYPE is set NON, the following pages will display:





If the TEMP. TYPE is set ROOM TEMP., the following pages will display:




Use the room thermostat to turn on or off the unit for space heating or cooling.
 ① The room thermostat is set to YES(see "ROOM THERMOSTAT SETTING" on «Installation, User and Service Manual») the unit is turned on or off by the room thermostat, press  on the interface, the following page will display:




② DUAL ROOM THERMOSTAT is set YES(see "ROOM THERMOSTAT SETTING" in «Installation, User and Service Manual»). The room thermostat for fan coil is turned off ,the room thermostat for the floor heating is turned on,and the unit is running, but the display is OFF. The following page is displayed:




Use the interface to turn on or off the unit for DHW. Press "▶", "▼" on home page, the black cursor will appear:




2) When the cursor is on DHW operation mode. Press  key to turn on/off the DHW mode.

If the space operation is ON, the following pages will display:




If the space operation mode is OFF, the following pages will display:










5.3 Adjusting the temperature

Press "◀", "▲" on home page, the black cursor will appear:





- If the cursor is on the temperature, use the "◀", "▶" to select and use "▼", "▲" to adjust the temperature.







5.4 Adjusting space operation mode

- Adjusting space operation mode by interface. Go to "MENU" > "SPACE OPERATION MODE". Press , the following page will appear:



- There are three modes to be selected including HEAT, COOL and AUTO mode. Use the "◀", "▶" to scroll, press ↵ to select. Even if you don't press ↵ button and exit the page by pressing ⏪ button, the mode would still effective if the cursor have been moved to the operation mode.


If there is only HEAT(COOL) mode, the following page will appear:



- The operation mode can not be changed see cool MODE SETTING on Installation, User and Service Manual.

If you select...	Then the space operation mode is
 heat	Always heating mode
 cool	Always cooling mode
 auto	<p>Automatically changed by the software based on the outdoor temperature (and depending on installer settings of the indoor temperature), and takes monthly restrictions into account.</p> <p>Note: Automatic changeover is only possible under certain conditions.</p> <p>See the FOR SERVICEMAN> AUTO MODE SETTING in «Installation, User and Service Manual».</p>

- Adjust space operation mode by the room thermostat, see "ROOM THERMOSTAT" on «Installation, User and Service Manual». Go to MENU>OPERATION MODE, if you press any key to select or adjust, the following page will appear:



6 INSTALLATION MANUAL

6.1 Safety precaution

- Read the safety precautions carefully before installing the unit.
- Below statements are important safety issues that must be obeyed.
- Conform there is no abnormal phenomena during test operation after completion, then hand the manual to the user. Meaning of marks:

WARNING

Means improper handling may lead to personal death or severe injury.

CAUTION

Means improper handling may lead to personal injury or property loss.

WARNING

Please entrust the distributor or professionals to install the unit. Installation by other persons may lead to imperfect installation, electric shock or fire.

Strictly follow this manual.

Improper installation may lead to electric shock or fire.

Reinstallation must be performed by professionals.

Improper installation may lead to electric shock or fire.

Do not disassemble your unit at will.

A random disassembly may cause abnormal operation or heating, which may result in fire.

CAUTION

Do not install the unit in a place vulnerable to leakage of flammable gases.

Once flammable gases are leaked and left around the wired controller, fire may occur.

The wiring should adapt to the wired controller current.

Otherwise, electric leakage or heating may occur and result in fire.

The specified cables shall be applied in the wiring. No external force may be applied to the terminal.

Otherwise, wire cut and heating may occur and result in fire.

Do not place the wired remote controller near heat sources*, to avoid the remote signal of the controller to be disturbed.

*fireplace, heaters, lamps, candles, direct sunlight



6.2 Other Precautions

6.2.1. Installation location

Do not install the unit in a place with much oil, steam, sulfide gas. Otherwise, the product may deform and fail.

Install in the room where the user spends most of their time, in a draught-free environment.

Check that the distance between the thermostat and the appliance does not exceed 50 meters (maximum cable length).

6.2.2 Preparation before installation

1) Check whether the following assemblies are complete.

No.	Name	Qty.	Remarks
1	Wired Controller	1	_____
2	Cross round head wood mounting screw	3	For Mounting on the Wall
3	Cross round head mounting screw	2	For Mounting on the Electrical Switch Box
4	Installation, User and Service Manual	1	_____
5	Plastic bolt	2	This accessory is used when install the centralized control inside the electric cabinet
6	Plastic expansion pipe	3	For mounting on the Wall

6.2.3 Note for installation of wired controller:


1) This installation manual contains information about the procedure of installing Wired Remote Controller. Please refer to the Installation, User and Service Manual» of the outside unit for connection between Wired Remote Controller and Indoor Unit.

2) Circuit of Wired Remote Controller is low voltage circuit. Never connect it with a standard 220V/380V circuit or put it into a same Wiring Tube with the circuit.


- 3) The shielded cable must be connected stable to the ground, or transmission may fail.
- 4) Do not attempt to extend the shielded cable by cutting, if it is necessary, use Terminal Connection Block to connect.
- 5) After finishing connection, do not use Megger to have the insulation check for the signal wire.

6.3 Installation procedure and matching setting of wired controller

6.3.1 Structure size figure



6.3.2 Wiring





Input Voltage(A/B)	13.5VAC
Wiring size	0.75mm ²





The rotating coded switch S3(0-F) on the main control board of hydraulic module is used for set the modbus address.







By default the units have this coded switch positioned=0, but this corresponds to the modbus address 16 , while the others positions corresponds the number, e.g. pos=2 is address 2, pos=5 is address 5.

6.3.3 Back cover installation






- 1) Use straight head screwdriver to insert in the buckling position in the bottom of wired controller, and spin the screwdriver to take down the back cover. (Pay attention to spinning direction, otherwise this will damage the back cover!)
- 2) Use three M4X20 screws to directly install the back cover on the wall.
- 3) Use two M4X25 screws to install the back cover on the 86 electrician box, and use one M4X20 screws for fixing on the wall.
- 4) Adjust the length of two plastic screw bars in the accessory to be standard length from the electrical box screw bar to the wall. Make sure while installing the screw bar to the wall, making it as flat as the wall.
- 5) Use cross head screws to fix the wired controller bottom cover in the wall through the screw bar. Make sure the wired controller bottom cover is on the same level after installation, and then install the wired controller back to the bottom cover.
- 6) Over fastening the screw will lead to deformation of back cover.




Avoid the water entering into the wired remote controller, use trap and putty to seal the connectors of wires during wiring installation.

6.4 Front cover installation

After adjusting the front cover and then buckle the front cover; avoid clamping the communication switching wire during installation.



Install correctly the back cover and firmly buckle the front cover and back cover, otherwise will make the front cover drop off.



7 MODBUS MAPPING TABLE

7.1 Modbus Port Communication Specification

Port: RS-485; the wired controller XYE is the communication port for connecting with the hydraulic module. H1 and H2 are the Modbus communication ports.

Communication address: It is consistent with the DIP switch address of the hydraulic module.

Baud rate: 9600.

Number of digits: Eight

Verification: none

Stop Bit: 1 bit

Communication protocol: Modbus RTU (Modbus ASCII is not supported)

7.1.1 Mapping of registers in the wired controller

The following addresses can use 03H, 06H (write single register), 10H (write multiple register)

Register address	Description	Remarks
0 (PLC:40001)	Power on or off.	BIT15 Reserved
		BIT14 Reserved
		BIT13 Reserved
		BIT12 Reserved
		BIT11 Reserved
		BIT10 Reserved
		BIT9 Reserved
		BIT8 Reserved
		BIT7 Reserved
		BIT6 Reserved
		BIT5 Reserved
		BIT4 Reserved
		BIT3 0:power off heat pump; 1: power on heat pump(zone 2)
		BIT2 0: DHW(T5S) power off; 1: DHW(T5S) power on
		BIT1 0:power off heat pump; 1: power on heat pump(zone 1)
BIT0 0: power off floor heating; 1: power on floor heating		

1 (PLC:40002)	Setting the mode	1: Auto; 2: Cool; 3: Heat; Others: Invalid	
2 (PLC:40003)	Setting water temperature T1s	Water temperature T1s is corresponding to the floor heating.	
3 (PLC:40004)	Setting air temperature Ts	The room temperature range is between 17°C and 30°C, and is valid when there is Ta.	
4 (PLC:40005)	T5s	The water tank temperature range is between 40°C and 60°C.	
5 (PLC:40006)	Function settin	BIT15	Reserved
		BIT14	Reserved
		BIT13	Reserved
		BIT12	1: curve setting is enabled; 0: curve setting is disabled.
		BIT11	DHW pump's running constant-temperature water recycling
		BIT10	ECO mode
		BIT9	Reserved
		BIT8	Holiday home (the status can only be read, not changed)
		BIT7	0: Silent mode level1; 1: Silent mode level2
		BIT6:	Silent mode
		BIT5:	Holiday away (the status can only be read, but cannot bechanged)
		BIT4:	Disinfect
BIT3:	Reserved		
BIT2:	Reserved		
BIT1:	Reserved		
BIT0:	Reserved		
6 (PLC:40007)	Curve selection	Curve 1-8	
7 (PLC:40008)	Forced water heating	0: Invalid 1: Forced on 2: Forced off	TBH is the electric water tank heater. IBH1 and 2 are the hydraulic module's rear electric heater. IBH1 and 2 can be activated together. TBH cannot be activated together with IBH1 and 2.
8 (PLC:40009)	Forced TBH		
9 (PLC:40010)	Forced IBH1		
10 (PLC:40011)	t_SG_MAX	0-24 Hours	

In cooling mode, T1S low temp setting range is 5~25°C; T1S high temp setting range is 18~25°C.
In heating mode, T1S low temp setting range is 22~55°C; T1S high temp setting range is 35~60°C.

7.1.2 When the wired controller is connected to the hydraulic module, the parameters of the whole unit can be checked:

Whole unit parameter mapping address table

1) Running parameters

Register address	Description	Remarks
100 (PLC:40101)	Operating frequency	Compressor operating frequency in Hz
101 (PLC:40102)	Operating Mode	Whole unit's actual operating mode, 2: cooling, 3: heating, 0: off
102 (PLC:40103)	Fan Speed	Fan speed, in r/min
103 (PLC:40104)	PMV openness	Openness of the outdoor unit's electronic expansion valve in P (only multiples of 8 are shown)
104 (PLC:40105)	Water inlet temperature	TW_in, in °C
105 (PLC:40106)	Water outlet temperature	TW_out, in °C
106 (PLC:40107)	T3 Temperature	Condenser temperature, in °C
107 (PLC:40108)	T4 Temperature	Outdoor ambient temperature in °C
108 (PLC:40109)	Discharge temperature	Compressor discharge temperature Tp in °C
109 (PLC:40110)	Return air temperature	Compressor air return temperature in °C
110 (PLC:40111)	T1	Total water outlet temperature in °C
111 (PLC:40112)	T1B	System total water outlet temperature (behind the auxiliary heater) °C

112 (PLC:40113)	T2	Refrigerant liquid side temperature in °C	
113 (PLC:40114)	T2B	Refrigerant gas side temperature in °C	
114 (PLC:40115)	Ta	Room temperature, in °C	
115 (PLC:40116)	T5	Water tank temperature	
116 (PLC:40117)	Pressure 1	Outdoor unit high pressure value, in kPA	
117 (PLC:40118)	Pressure 2	Outdoor unit low pressure value, in kPA	
118 (PLC:40119)	Outdoor unit current	Outdoor unit operating current, in A	
119 (PLC:40120)	Outdoor unit voltage	Outdoor unit voltage in V	
120 (PLC:40121)	Hydraulic module current 1	Hydraulic module current 1 in A (reserved)	
121 (PLC:40122)	Hydraulic module current 2	Hydraulic module current 2 in A (reserved)	
122 (PLC:40123)	Compressor operating time	Compressor operating time in hour	
123 (PLC:40124)	Reserved	Reserved	
124 (PLC:40125)	Current fault	Check the code table for detailed fault codes	
125 (PLC:40126)	Fault 1	Check the code table for detailed fault codes.	
126 (PLC:40127)	Fault 2		
127 (PLC:40128)	Fault 3		
128 (PLC:40129)	Status bit 1	BIT15	Reserved
		BIT14	Reserved
		BIT13	Reserved
		BIT12	Reserved
		BIT11	EUV 1:free electricity; 0:judge by SG's signal
		BIT10	SG 1:normal electricity; 0:high price electricity (judge when EUV is 0)
		BIT9	Reserved
		BIT8	Solar energy signal input
		BIT7	Room temperature controller cooling
		BIT6:	Room temperature controller heating
		BIT5:	Outdoor unit test mode mark
		BIT4:	Remote On/Off (1: d8)
		BIT3:	Oil return
		BIT2:	Anti-freezing
BIT1:	Defrosting		
BIT0:	Reserved		
129 (PLC:40130)	Load output	BIT15	DEFROST
		BIT14	External heater
		BIT13	RUN
		BIT12	ALARM
		BIT11	Solar water pump
		BIT10	HEAT4
		BIT9	SV2
		BIT8	Mixed water pump P_c
		BIT7	Water return water P_d
		BIT6:	External water pump P_o
		BIT5:	Reserved
		BIT4:	SV1
		BIT3:	Water pump PUMP_I
		BIT2:	Electric heater TBH
BIT1:	Reserved		
BIT0:	Electric heater IBH1		
130 (PLC:40131)	Whole unit version No.	1~99 is the whole unit's version number and refers to the hydraulic module's version number.	
131 (PLC:40132)	Wired controller version No.	1~99 is the wired controller's version number.	

132 (PLC:40133)	Unit target frequency	
133 (PLC:40134)	Dc bus current	In A
134 (PLC:40135)	Dc bus voltage	The actual value/10, in V
135 (PLC:40136)	TF module temperature	Feedback on outdoor unit,in °C
136 (PLC:40137)	Hydraulic module curve T1S calculated value 1	The corresponding calculated value of zone 1
137 (PLC:40138)	Hydraulic module curve T1S calculated value 2	The corresponding calculated value of zone 2
138 (PLC:40139)	Water flow	The actual value*100, in m3/H
139 (PLC:40140)	Limit scheme of outdoor unit current	Scheme value
140 (PLC:40141)	Ability of Hydraulic module	The actual value*100, in kW

2) Parameter setting

Registeraddress	Description	Remarks																																
200 (PLC:40201)	Home appliance type	The upper 8 bit is the home appliance type: Central heating: 0x07																																
201 (PLC: 40202)	Temperature upper limit of T1S cooling																																	
202 (PLC: 40203)	Temperature lower limit of T1S cooling																																	
203 (PLC: 40204)	Temperature upper limit of T1S heating																																	
204 (PLC: 40205)	Temperature lower limit of T1S heating																																	
205 (PLC: 40206)	Temperature upper limit of TS setting																																	
206 (PLC: 40207)	Temperature lower limit of TS setting																																	
207 (PLC: 40208)	Temperature upper limit of water heating																																	
208 (PLC: 40209)	Temperature lower limit of water heating																																	
209 (PLC: 40210)	PUMP RUNNING TIME	DHW PUMP water return running time. It is five minutes by default and can be adjusted between 5 and 120 min at an interval of 1 min.																																
210 (PLC: 40211)	Parameter setting 1	<table border="1"> <tr> <td>BIT15</td> <td>Enable water heating</td> </tr> <tr> <td>BIT14</td> <td>Supports water tank electric heater TBH(Read-only)</td> </tr> <tr> <td>BIT13</td> <td>Supports disinfection</td> </tr> <tr> <td>BIT12</td> <td>DHW PUMP, 1: supported; 0: not supported</td> </tr> <tr> <td>BIT11</td> <td>Reserved</td> </tr> <tr> <td>BIT10</td> <td>DHW pump supports Pipe Disinfect</td> </tr> <tr> <td>BIT9</td> <td>Enable cooling</td> </tr> <tr> <td>BIT8</td> <td>T1S cooling high/low temperature settings(Read-only)</td> </tr> <tr> <td>BIT7</td> <td>Enable heating</td> </tr> <tr> <td>BIT6:</td> <td>T1S heating high/low temperature settings(Read-only)</td> </tr> <tr> <td>BIT5:</td> <td>Supports T1 sensor</td> </tr> <tr> <td>BIT4:</td> <td>Supports room temperature Sensor Ta</td> </tr> <tr> <td>BIT3:</td> <td>Supports room thermostat</td> </tr> <tr> <td>BIT2:</td> <td>Room thermostat</td> </tr> <tr> <td>BIT1:</td> <td>Dual Room Thermostat, 0: not supported; 1: supported</td> </tr> <tr> <td>BIT0:</td> <td>0: room cooling/heating first, 1: water heating first</td> </tr> </table>	BIT15	Enable water heating	BIT14	Supports water tank electric heater TBH(Read-only)	BIT13	Supports disinfection	BIT12	DHW PUMP, 1: supported; 0: not supported	BIT11	Reserved	BIT10	DHW pump supports Pipe Disinfect	BIT9	Enable cooling	BIT8	T1S cooling high/low temperature settings(Read-only)	BIT7	Enable heating	BIT6:	T1S heating high/low temperature settings(Read-only)	BIT5:	Supports T1 sensor	BIT4:	Supports room temperature Sensor Ta	BIT3:	Supports room thermostat	BIT2:	Room thermostat	BIT1:	Dual Room Thermostat, 0: not supported; 1: supported	BIT0:	0: room cooling/heating first, 1: water heating first
BIT15	Enable water heating																																	
BIT14	Supports water tank electric heater TBH(Read-only)																																	
BIT13	Supports disinfection																																	
BIT12	DHW PUMP, 1: supported; 0: not supported																																	
BIT11	Reserved																																	
BIT10	DHW pump supports Pipe Disinfect																																	
BIT9	Enable cooling																																	
BIT8	T1S cooling high/low temperature settings(Read-only)																																	
BIT7	Enable heating																																	
BIT6:	T1S heating high/low temperature settings(Read-only)																																	
BIT5:	Supports T1 sensor																																	
BIT4:	Supports room temperature Sensor Ta																																	
BIT3:	Supports room thermostat																																	
BIT2:	Room thermostat																																	
BIT1:	Dual Room Thermostat, 0: not supported; 1: supported																																	
BIT0:	0: room cooling/heating first, 1: water heating first																																	

211 (PLC:40212)	Parameter setting 2	BIT15	Reserved
		BIT14	Reserved
		BIT13	Reserved
		BIT12	Reserved
		BIT11	Reserved
		BIT10	Reserved
		BIT9	Reserved
		BIT8	Define the port, 0=remote ON/OFF; 1=DHW heater
		BIT7	Smart grid, 0=NON; 1=YES
		BIT6:	Enable or disable the Tw2, 0=NON ; 1=YES
		BIT5:	Setting the high/low temperature of cooling mode T1S
		BIT4:	Setting the high/low temperature of heating mode T1S
		BIT3:	Double zone setting is valid
		BIT2:	Reserved
		BIT1:	Reserved
		BIT0:	Reserved
212 (PLC: 40213)	dT5_On	Default setting: 5°C, range: 2~10°C, setting interval: 1°C	
213 (PLC: 40214)	dT1S5	Default setting: 10°C, range: 5~40°C, setting interval: 1°C	
214 (PLC: 40215)	T_Interval_DHW	Default setting: 5 min, range: 5~30 min, setting interval: 1 min	
215 (PLC: 40216)	T4DHWmax	Default setting: 43°C, range: 35~43°C, setting interval: 1°C	
216 (PLC: 40217)	T4DHWmin	Default setting: -10°C, range: -25~5°C, setting interval: 1°C	
217 (PLC: 40218)	t_TBH_delay	Default setting: 30 min, range: 0~240 min, setting interval: 5 min	
218 (PLC: 40219)	dT5_TBH_off	Default setting: 5°C, range: 0~10°C, setting interval: 1°C	
219 (PLC: 40220)	T4_TBH_on	Default setting: 5°C, range: -5~20°C, setting interval: 1°C	
220 (PLC: 40221)	T5s_DI	Temperature of the disinfection water tank, range: 60~70°C, default setting: 65°C	
221 (PLC: 40222)	t_DI_max	Maximum disinfection duration, range: 90~300 min, default setting: 210 min	
222 (PLC: 40223)	t_DI_hightemp	Disinfection high temperature duration, range: 5~60 min, default setting: 15 min	
223 (PLC: 40224)	t_interval_C	Time interval of compressor start-up in cooling mode; range: 5~30 min, default setting: 5 min	
224 (PLC: 40225)	dT1SC	Default setting: 5°C, range: 2~10°C, setting interval: 1°C	
225 (PLC: 40226)	dTSC	Default setting: 2°C, range: 1~10°C, setting interval: 1°C	
226 (PLC: 40227)	T4cmax	Default setting: 43°C, range: 35~46°C, setting interval: 1°C	
227 (PLC: 40228)	T4cmin	Default setting: 10°C, range: -5~25°C, setting interval: 1°C	
228 (PLC: 40229)	t_interval_H	Time interval of compressor start-up in the heating mode; range: 5~60 min, default setting: 5 min	
229 (PLC: 40230)	dT1SH	Default setting: 5°C, range: 2~10°C, setting interval: 1°C	
230 (PLC: 40231)	dTSH	Default setting: 2°C, range: 1~10°C, setting interval: 1°C	
231 (PLC: 40232)	T4hmax	Default setting: 25°C, range: 20~35°C, setting interval: 1°C	
232 (PLC: 40233)	T4hmin	Default setting: -15°C, range: -25~5°C, setting interval: 1°C	
233 (PLC: 40234)	T4_IBH_on	Ambient temperature for enabling the hydraulic module auxiliary electric heating IBH, range: -15~10°C; default setting: -5°C	
234 (PLC: 40235)	dT1_IBH_on	Temperature return difference for enabling the hydraulic module auxiliary electric heating IBH, range: 2~10°C; default setting: 5°C	
235 (PLC: 40236)	t_IBH_delay	Delay time of enabling the hydraulic module auxiliary electric heating IBH, range: 15~120 min; default setting: 30 min	

237 (PLC: 40238)	T4_AHS_on	Ambient temperature for enabling the external heater AHS, range: -15~10°C, setting interval: -5°C
238 (PLC: 40239)	dT1_AHS_on	Temperature return difference for enabling the external heater AHS, range: 2~10°C; default setting: 5°C
240 (PLC: 40241)	t_AHS_delay	Delay time for enabling the external heater AHS, range: 5~120 min; default setting: 30 min
241 (PLC: 40242)	t_DHWHP_max	Longest duration of water heating by the heat pump, range: 10~600 min, default setting: 120 min;
242 (PLC: 40243)	t_DHWHP_restrict	Duration of limited water heating by the heat pump, range: 10~600 min, default setting: 30 min;
243 (PLC: 40244)	T4autocmin	Default setting: 25°C, range: 20~29°C, setting interval: 1°C
244 (PLC: 40245)	T4autohmax	Default setting: 17°C, range: 10~17°C, setting interval: 1°C
245 (PLC: 40246)	T1S_H_A_H	In the holiday mode, setting of T1 in the heating mode, range: 20~25°C, default setting: 25°C
246 (PLC: 40247)	T5S_H_A_DHW	In the holiday mode, setting of T1 in the water heating mode, range: 20~25°C, default setting: 25°C
247 (PLC: 40248)	ECO parameter	Reserved, wrong address is reported when this register is queried
248 (PLC: 40249)	ECO parameter	Reserved, wrong address is reported when this register is queried
249 (PLC: 40250)	ECO parameter	Reserved, wrong address is reported when this register is queried
250 (P LC:40251)	ECO parameter	Reserved, wrong address is reported when this register is queried
251 (PLC: 40252)	Comfort parameter	Reserved, wrong address is reported when this register is queried
252 (P LC:40253)	Comfort parameter	Reserved, wrong address is reported when this register is queried
253 (PLC: 40254)	Comfort parameter	Reserved, wrong address is reported when this register is queried
254 (P LC:40255)	Comfort parameter	Reserved, wrong address is reported when this register is queried
255 (PLC: 40256)	t_DRYUP	Temperature rise day number, range: 4~15 days, default setting: 8 days
256 (PLC: 40257)	t_HIGHPEAK	Drying day number, range: 3~7 days, default setting: 5 days
257 (PLC: 40258)	t_DRYD	Temperature drop day number, range: 4~15 days, default setting: 5 days
258 (PLC: 40259)	T_DRYPEAK	Highest drying temperature, range: 30~55°C, default setting: 45°C
259 (PLC: 40260)	t_firstFH	Running time of floor heating for the first time, default setting: 72 hrs, range: 48-96 hrs
260 (PLC: 40261)	T1S (first floor heating)	T1S of floor heating for the first time, range: 25~35°C, default setting: 25°C
261 (PLC: 40262)	T1SetC1	Parameter of the ninth temperature curves for cooling mode, range:5~25°C, default setting: 10°C;
262 (PLC: 40263)	T1SetC2	Parameter of the ninth temperature curves for cooling mode, range:5~25°C, default setting: 16°C;
263 (PLC: 40264)	T4C1	Parameter of the ninth temperature curves for cooling mode, range: (-5)~46°C, default setting: 35°C;
264 (PLC: 40265)	T4C2	Parameter of the ninth temperature curves for cooling mode, range: (-5)~46°C, default setting: 25°C;
265 (PLC: 40266)	T1SetH1	Parameter of the ninth temperature curves for cooling mode, range:25~60°C, default setting: 35°C;
266 (PLC: 40267)	T1SetH2	Parameter of the ninth temperature curves for cooling mode, range:25~60°C, default setting: 28°C;
267 (PLC: 40268)	T4H1	Parameter of the ninth temperature curves for cooling mode, range: (-25)~30°C, default setting: -5°C;
268 (PLC: 40269)	T4H2	Parameter of the ninth temperature curves for cooling mode, range: (-25)~30°C, default setting: 7°C;

269 (PLC: 40270)		The type of power input limitation, 0=NON, 1~8=type 1~8, default:0
270 (P LC: 40271)	HB:t_T4_FRESH_C	range:0.5~6 hour, setting interval:0.5 hour, sending value=actual value*2
	LB:t_T4_FRESH_H	range:0.5~6 hour, setting interval:0.5 hour, sending value=actual value*2
271 (PLC: 40272)	T_PUMPI_DELAY	range:2~20 hour, setting interval:0.5 hour, sending value=actual value*2:
272 (PLC: 40273)	EMISSION TYPE	Bit12-15: The type of zone 2 end for cooling mode
		Bit8-11: The type of zone 1 end for cooling mode
		Bit4-7: The type of zone 2 end for heating mode
		Bit0-3: The type of zone 1 end for heating mode

7.1.3 Code table

Error code	Value	Content
E0	1	Water flow fault(E8 displayed 3 times)
E1	2	Phase loss or neutral wire and live wire are connected reversely(only for three phase unit)
E2	3	Communication fault between controller and hydraulic module
E3	4	Final outlet water temp. sensor(T1) fault
E4	5	Water tank temp. sensor(T5) fault
E5	6	The condenser outlet refrigerant temperature sensor(T3) fault
E6	7	The ambient temperature sensor(T4) fault
E7	8	Buffer tank up temp. sensor(Tbt1) fault
E8	9	Water flow failure
E9	10	Suction temp. sensor (Th) fault
EA	11	Discharge temp. sensor (Tp) fault
Eb	12	Solar temp. sensor(Tsolar) fault
Ec	13	Buffer tank low temp. sensor(Tbt2) fault
Ed	14	Inlet water temp. sensor(Tw_in) malfunction
EE	15	Hydraulic module EEprom failure
P0	20	Low pressure switch protection
P1	21	High pressure switch protection
P3	23	Compressor overcurrent protection
P4	24	High discharge temperature protection
P5	25	Tw_out - Tw_in value too big protection
P6	26	Inverter module protection
Pb	31	Anti-freeze mode
Pd	33	High temperature protection of refrigerant outlet temp. of condenser
PP	38	Tw_out - Tw_in unusual protection
H0	39	Communication fault between main board PCB B and main control board of hydraulic module
H1	40	Communication fault between inverter module PCB A and main control board PCB B
H2	41	Refrigerant liquid temp. sensor(T2) fault
H3	42	Refrigerant gas temp. sensor(T2B) fault
H4	43	Three times L0/L1 protection
H5	44	Room temo. sensor (Ta) fault
H6	45	DC fan motor fault
H7	46	Voltage protection

Error code	Value	Content
H8	47	Pressure sensor fault
H9	48	Outlet water for zone 2 temp. sensor(Tw2) fault
HA	49	Outlet water temp. sensor(Tw_out) fault
Hb	50	3 times PP protection and Tw_out<7℃
Hd	52	Communication fault between hydraulic module parallel
HE	53	Communication error between main board and thermostat transfer board
HF	54	Inverter module board EE PROM fault
HH	55	H6 display 10 times in 2 hours
HP	57	Low pressure protection (Pe<0.6) occurred 3 times in 1 hour
C7	65	Transducer module temperature too high protection
bH	112	PED PCB fault
F1	116	Low DC generatrix voltage protection
L0	134	Module protection
L1	135	DC generatrix low voltage protection
L2	136	DC generatrix high voltage protection
L4	138	MCE fault
L5	139	Zero speed protection
L7	141	Phase sequence fault
L8	142	Speed difference > 15Hz protection between the front and the back clock
L9	143	Speed difference > 15Hz protection between the real and the setting speed

BAXI

For United Kingdom
www.baxi.co.uk
0344 871 1545

Baxi, Brooks House
Coventry Road, Warwick, CV34 4LL.

For Ireland
www.baxipottertonmyson.ie
00353 (0)1 4590870

Baxi Potterton Myson
Unit F 5&6, Calmount Park, Calmount Road,
Ballymount , Dublin 12, Ireland.

BDR THERMEA GROUP

7799027 - v03 - 08022022



7799027-001-03

