

ANTI VIBRATION FEET 400 MM

GENERAL WARNINGS.

All Alpha products must be protected with an adequate transport packaging. The material must be stored in a dry place protected from the weather.

This instruction manual provides technical information for the installation of the Alpha kit.

As for the other issues related to the installation of the kit (e.g. safety in the workplace, environmental protection, accident prevention), it is necessary to comply with the provisions specified in the regulations in force and with the principles of good practice.

Improper installation or assembly of the Alpha appliance and/or components, accessories, kits and devices can cause unexpected problems for people, animals and objects. Read the instructions provided with the product carefully to ensure proper installation.

Installation and maintenance must be performed in compliance with the regulations in force, according to the manufacturer's instructions and by professionally qualified staff, meaning staff with specific technical skills in the plant sector, as envisioned by the law.

Attention: The maximum weight allowed for rubber base is 200 kg.

INSTALLION:

Proceed as follows to assemble the vulcanized rubber anti-vibration kit under the heat pump:

- Insert the screws (3) inside the aluminum profile (2) (Fig.1).
- Position the rubber base (1) under the heat pump, adjusting the position of the screws (3) making sure that they fit into the slots on the heat pump brackets.
- At this point it is possible to tighten the nuts (5) and washers (4) on the screws (3) making sure that the rubber base (1) is firmly under the heat pump.
- Proceed to mount the two remaining rubber bases by repeating the previous steps.

NB: The orientation of the rubber bases must be as shown in Fig. 2

