

# **Overflow Waste System**


A 21.5mm solvent weld overflow system in PVC-U with an extensive range of fittings to meet most installation requirements.

## **Fixing Guide**

- Fix pipe brackets at maximum 0.6m centres for both vertical and horizontal runs.
- No expansion gap required on the solvent weld overflow system.
- Solvent weld joints in accordance with ABS/PVC-U Waste Systems instructions.



# 21.5mm Overflow Waste **PVC-U Solvent**







CODE

### Overflow Waste Reducer



x32mm x40mm

Fits both push-fit and solvent weld systems



OS14 STRAIGHT TANK CONNECTOR

# flexiflo Connectors

- Flexible range of connectors, suitable for a wide variety of applications.
- Will fit all pipes (PVC/Copper/Lead etc) within each specific size range.
- Elbows and Tees must not be used in underground installation situations. End Caps can be used as temporary blanking plugs.



# Coupling



CODE 30-38mm 38-45mm



40-48mm 105-116mm

