## Care and cleaning instructions, For Thermoset and Thermoplastic Toilets seats:

- The seat and cover should be cleaned using warm soapy water.
- Do not use aggressive or abrasive cleaners as this may scratch the surface of the seat.
- The hinges should be cleaned using soap, or a mild detergent. After cleaning, the hinges should be rinsed in clean water and dried.
- Never use bleach, concentrated cleaners or acids on the hinges as this will cause discolouring and pitting.
- Do not leave bleach in the toilet blow with the cover because this may cause discolouration of the seat and hinges.
- Take care not to splash the hinges when using bleach in toilet bowl.

The cover supplied with this toilet seat is for decorative purposes only. For example, it should not be used as a step or stool.

Wirquin Itd - Warmsworth Halt Industrial Estate - Warmsworth - Doncaster DN49LS
<u>www.wirquin.co.uk</u> – Sales@wirquin.co.uk

