

Installation Instructions & User Guide

Please leave these instructions with the end user

Product Code: VAX SNK C (D2)

Inlet Connections

Specifications

Dynamic Water Pressure










Maximum Static Pressure: 10.0 bar


Inlet Water Temperature

Cold Water Supply









Tools You'll Need





Prior to Installation

All products manufactured and supplied by Bristan are safe provided they are installed, used correctly and receive regular maintenance in accordance with these instructions.


This product has been tested to the Water Regulations Advisory Scheme (WRAS) and satisfies the requirements of the Water Supply (Water Fittings) Regulations 1999 and current bylaws. For full Installation Requirements & Notes (IRN) please visit wras.co.uk/directory.

We recommend isolation valves to be fitted to the inlet water supplies to ensure ease of future maintenance.

Before installing these taps the water supply must be thoroughly flushed in order to remove any swarf, solder etc.

This product must not be modified in any way as this will invalidate the guarantee.


Pack Contents




Spare Parts

To replace any spare parts for your tap, why not scan the QR Code or visit www.bristan.com and search for your product.







Maintenance - Clea	3 0	
Remove handles.		
IMPORTANT Isolate the water supply before starting!	Remove the valves using a suitable spanner.	Place valves in a suitable solution and soak until fully de-scaled.
Replace the valves.	Replace the handles.	6
Love Your Chrome		
Bristan offers an offestive chrom	po-friendly cleaning kit	Turn on the mains

Bristan offers an effective chrome-friendly cleaning kit

for use with your taps and showers. Scan the QR Code

or search for 'CLEAN KIT01' on www.bristan.com.

l	Troubleshooting				
l	Symptom	Cause	Remedy		
	No flow or low flow rate	Partially closed isolation valve.	Open isolation valve.		
		Instantaneous water heater cycles on and off as flow rate or pressure is too low.	Increase water flow rate or pressure through system.		
		Head of water is below the minimum distance required.	Refer to specification for minimum distance required.		
		Hot or cold water being drawn off elsewhere causing pressure changes or instantaneous boiler temperature changes.	Do not use other water outlets when using the taps.		
		Airlock or partial blockage in the supply pipework.	Flush through pipework to ensure removal of debris and any airlocks.		
	\A/atox	This is normal for a short time after using	This is caused by residual water tension, the build up		

Notes

water supply, letting

the water flow for

a few minutes to flush

through the system.

Water

dripping

from taps

Taps do not turn on

the taps.

If water continues to drip,

Mains water supply turned off.

Closed isolation valve.

possibly due to the ceramic disc valves

Please use this space for any notes you or your installer may have regarding the installation/plumbing of this product.

of water in the tap body.

Turn on mains water supply.

Open isolation valve.

Remove valves and clean, refer to 'Maintenance'

section before starting any maintenance.

At Bristan, we want to make things as easy as possible for our customers.

That's why we offer solid guarantees on all our products, effective from the date of purchase, to give you peace of mind.

To start your free guarantee simply scan the QR code and register your product.
Alternatively visit **www.bristan.com/register** to register your product via a computer.



