

MULTIPANEL®

Linda Barker Collection
Heritage Collection
Classic Collection

Recommended Tools

- Ruler
- Pencil
- Masking Tape
- Measuring Tape
- Silicone Sealant
- Drill & Screwdriver
- High-grab adhesive
- Jig saw or Hand saw


INSTALLATION GUIDE

Pre-installation







Prior to installation, Multipanel recommend that you visit our **video** section on www.multipanel.co.uk, where you will find a complete animation.

Pre-installation check-list

Checked?







Panels are supplied with clear protective polycoating to the face, and white laminate to the rear. The clear polycoating should be carefully peeled back to inspect the surface, and replaced for installation. This is particularly important where polycoating has text over-printed.		Remove Protective Film	Y / N
Inspect wall panels for any flaws, defects or damage.			Y / N
Check colour and pattern concentration consistency between all panels and profiles.			Y / N
If panels are being fitted by a tradesman, colours should be approved by end user.			Y / N
Please ensure to read this guide in full before commencing installation.			Y / N
Once installation has commenced the panels are deemed to have arrived in perfect condition, any of the above reported after installation will not be covered by your warranty.			

CONDITIONING AND STORAGE

					
Panels should always be carried by two people	Panels should not be stored in areas of high humidity	Do not store outside or leant angled against a wall	Store in cool dry conditions between 5-25°C	Store flat and horizontal to prevent bowing	Condition panels & adhesive at room temp. for 48-72 hours

WALL PREPARATION, HANDLING AND CUTTING

Panels can be fixed to most surfaces including tiles, concrete, plaster, plasterboard, and chipboard/plywood walls providing they are sound.

	Softwood grounds should be applied over poor surfaces, set approximately at 60cm vertically and 80cm horizontally as appropriate.		To ensure your Multipanel® Reflect is properly bonded, ensure all surfaces to which adhesive will be applied are clean and dry.		When using an upward cutting blade (jigsaw) or a circular saw, panels should be cut face down to avoid chipping.
	Gloves should be worn at all times when handling panels. Protective eyewear should be worn when cutting panels.		Measure and mark your required cutting line.		When using a fine toothed handsaw, panels should be cut decorative face up.

When measuring distance from walls, or passed shower enclosures, allowances should be made for the thickness of aluminium profiles and the space between walls and profiles.



MULTIPANEL®

Don't tile it. Multipanel it.

FIXING PANELS AND PROFILES

All panels must be properly sealed at all vertical edges, whether they are being attached to profiles, shower enclosures or hydrolocked. Panels must also ALWAYS be silicone sealed at the base, whether using Multipanel® seal kit, with or without extrusions. Inadequate sealing will invalidate your warranty. If the seal starts to deteriorate, it must be re-sealed immediately, and not allow moisture to penetrate joints or junctions.




The first profile, normally start with an Internal Corner or End Cap, should be fixed to the wall or end grounds with countersunk screws, or adhesive and a bead of silicone sealant applied to the channel



Apply silicone to the inside of the first profile



Apply silicone sealant to the channel of the second profile and attach it to the long edge of first panel.



Apply adhesive to the reverse of the panel, angle into the first profile and push firmly against the wall.



Alternatively, you can apply adhesive directly to the wall or timber framework.


FIXING HYDROLOCK PANELS

Prior to installation, it is strongly recommended that hydro-lock panels are conditioned in the room (or similar environment) where they will be installed for 48-72 hours. This is particularly important in cold conditions. Hydro-lock tongue and groove panels should be dry jointed prior to final installation to ensure a sufficiently flush and tight joint will be achieved between all panels. Hydro-lock panels MUST be silicone sealed at all vertical joints, as well as at all extrusions, joints and at the bottom of the panel.

Hydrolock panels can be screw-fixed or bonded to the wall with high-grab adhesive. Screws should be at 400 – 600mm centres with the bottom screw a maximum of 35mm from the bottom edge of the panel.



Hydrolock panels are supplied as standard with a tongued long edge and a grooved long edge. When fitting panels into an extrusion, the protruding tongued or grooved edge should be cut off.



Bond the first panel to the wall or frame, with the grooved edge first. If screw fixing panels to the wall/frame, pilot bore the recess in the groove where screws are to be located. (failure to pilot bore may result in the panels splitting). Pack between back of panel and wall as necessary to avoid distortion to the Hydro-lock joint when screw fixing.




When manufacturing hydro-lock joints, 20mm is lost from the original panel width – please allow for this when calculating panel requirements, e.g,

- 2400x598mm = 2400x579.5mm finished face size.
- 2400x1200mm = 2400x1181.5mm finished face size.



Fix through the back flange of the grooved edge with countersunk screws - the screw head should fit into the recess on the back of the tongue. Ensure that screws are turned until they are just under the flush to prevent any obstruction to the tongue of the next panel to be fitted.



Apply masking tape to the two meeting edges of the decorative face to protect the laminate face. Apply a narrow bead (2-3mm) of silicone sealant to the front shoulder of the tongue.



Starting at approximately 45°, angle the tongue of the next panel into the groove of the fixed panel. Ensure the tongue is fully inserted into the groove before snapping it back to the wall, otherwise it may damage the joint.



Remove the masking tape and ensure any excess silicone sealant is wiped from the laminate face immediately.



SHOWER TRAYS AND BATHS - FIGURE 1

Multipanel® Seal is an all-in-one kit for sealing the bottom edge of Multipanel® at a shower tray or bath. See separate installation guide.

Alternatively you can fit Multipanel® with a 3mm gap between the edge of the panel and the shower tray or baths, sealing the gap with silicone sealant.

WET AREAS - FIGURE 2

In wet areas, we recommend the use of an aluminium Type X base profile. Height adjustments should be made where the panel meets the ceiling. Floor covering material should continue approx. 100mm up the wall behind the panels. Screw fix the profile through the floor covering into the wall/frame, and apply silicone sealant to the base and the back of the profile.





MULTIPANEL®

Don't tile it. Multipanel it.

WINDOW DETAIL - FIGURE 3

At windowsills, a Type E quadrant end cap should be used between panels, and mitred in the corners.

FITTING VALVES AND CONTROLS


When cutting apertures or drilling into Multipanel®, a 2mm clearance gap should be left around all edges, and sealed with silicone sealant.

ADHESIVES AND SEALANTS

Multipanel® Panel adhesive and sealant are available to order from your distributor or local show room.

AFTERCARE

Once installed, your Multipanel® requires minimal maintenance. Multipanel® should be cleaned with warm water and a non-abrasive mild detergent. Scouring products or similar products should not be used, and doing so may invalidate your warranty.



DOMESTIC WARRANTY

Grant Westfield Ltd offers a 15 year warranty that Multipanel® panels will not crack, blister or delaminate and will remain watertight if fitted and sealed in accordance with our published recommendations.

In the event of a successful claim under your Multipanel® guarantee we will replace the panels, but will only cover any claims for consequential costs under exceptional circumstances where a defective panel prohibits ordinary use of the surrounding area.

This guarantee does not cover failure of the product due to:

- Faulty installation
- Incorrect maintenance or storage - panels should not be leaned against walls, or balanced between tressels. If panels have been stored in extremely cold conditions, they should be conditioned at room temperature for 48 hours prior to installation.
- Damage or misuse

Prior to installation the following checks should be carried out and any queries reported, as claims of this nature will not be covered:

- Colour matching and sheen levels between all panels and profiles
- If panels are to be fitted by a tradesman - colours should 1st be approved by the customer
- All products have arrived in good condition
- Dry fit hydro-lock tongue and groove jointed boards prior to final installation to ensure a flush finish and ensure tightly butted joints
- Flaws or defects in laminate - although unlikely. Where protective poly coating has text over printed, this should be removed to check the laminate.

This guarantee does not confer any rights other than those set out above and claims for consequential loss or damage are excluded. This guarantee does not affect your statutory rights as a consumer.